



V6 Instruction

1.Login in




Domestic users register with mobile phone number, foreign users register and login using mail address, and enter the "my" page after login.







2, Bound gateway

There are two ways bound the gateway.

(1) Gateway Center → Gateway list → (plus sign at top right corner) bound gateway → input the gateway number and password (If it's your first time to use this gateway, the default password is the last 6 numbers of the serial number)





(2) Device → Add devices → Gateway → follow the step shows on page after the selection of the corresponding gateway





3. Using the devices

Add the device(According to the step show on the screen) → add successful →
Device list → Details of device




4. Use the scene. The first page scene is the default of the most out of the 7, click more to view all the scene, can add the scene and the existing scene sort, When the scene is added, it can be operated step by step according to the page boot process.



5. Use a housekeeper


My → my housekeeper → add the house keeper task (click the upper right corner plus sign)
→ open / close the housekeeper



6.Setting

Contains functions:

- (1) Modify the password and bind the mailbox.
- (2) Open / close the account push, select the alarm voice, set the alarm time section
- (3) Change the App color.



Log Out

7. Check information

(1) The version of APP

(2) The version of gateway \longrightarrow gateway setting \longrightarrow Device information

